

11900 BEAD SEAT BAND INSTALLER

Bead Seat Band Installer

- Uses hydraulic force to install bead seat bands in earthmover tires
- 25 tons of hydraulic force to ensure that all bead seat bands are installed effortlessly
- The angled plate rests against a large section of the tire, ensuring protection of the bead during installation
- Weight: 40 lbs (18.1 kg)







2347 Circuit Way Brooksville, FL 34604 352.799.1111 - sales@ameintl.net










11900 BEAD SEAT BAND INSTALLER

Bead Seat Band Installer



2347 Circuit Way Brooksville, FL 34604 352.799.1111 - sales@ameintl.net





