




INSTRUCTION MANUAL

#11060 DUAL AGRICULTURE TIRE BEAD BREAKER



11060 Parts Breakdown



ITEM	PRODUCT NO.	DESCRIPTION	QTY
1	11060-001	OUTSIDE FRAME	1
2	11060-002	INSIDE FRAME	1
3	11060-003	PUSH SPADE	1
4	11060-004	RAM	1
5	11060-005	ELBOW	1
6	11060-006	HYDRAULIC HOSE	1
7	11060-007	3/8" FEMALE ADAPTER	1
8	11060-008	COUPLER	1
9	11060-009	SHOULDER BOLT 3 1/4"	1
10	11060-010	SHOULDER BOLT 3 3/4"	1
11	11060-011	LOCK NUT	2
12	11060-012	RETAINER BOLT	1
13	11060-013	LOCK NUT 1/4"	1
14	11060-014	LOCK NUT 1/2"	1
15	11060-015	FLAT WASHER	1
16	11060-016	BOLT GRADE 8 1/2"	1
18	11060-018	SEAL REPAIR KIT	1